

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-23353</u>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. OG-6008
7. Lease Name or Unit Agreement Name  State E
8. Well No. 1
9. Pool name or Wildcat <u>Permian</u> North Bagley, Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator <u>Read &amp; Stevens, Inc.</u>	
3. Address of Operator <u>P.O. Box 1518, Roswell, NM 88202</u>	
4. Well Location <u>2c93</u> Unit Letter <u>N</u> : <u>1980</u> Feet From The <u>W</u> Line and <u>660</u> Feet From The <u>S</u> Line Section <u>7</u> Township <u>11S</u> Range <u>33E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set CIBP @ 8590' and spot 35 sx cmt on top.  
Set 100' cmt @ top of ABO (7340').  
Cut & pull 5 1/2" csg from 5000'.  
Set 100' plug in stub & tag.  
Set 100' plug in 8 5/8" shoe (3720').  
Cut & pull 8 5/8" csg and set 100' plug in stub & tag.  
Set 100' plug @ 12 3/4" shoe (378').  
Set 10 sx surf plug.  
Circ hole w/10# mud laden fluid prior to pumping any cmt.  
Install DH marker, clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE John M. [Signature] TITLE Petroleum Engineer DATE 7-31-90  
TYPE OR PRINT NAME \_\_\_\_\_ TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

ORIGINAL SIGNED BY JERRY Y. SEXTON  
DISTRICT SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE AUG - 2 1990

CONDITIONS OF APPROVAL, IF ANY:

xc: Carl, File