

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Midwest Oil Corporation		5. State Oil & Gas Lease No. K-5742
3. Address of Operator Box 2010, Hobbs, New Mexico 88240		7. Unit Agreement Name
4. Location of Well UNIT LETTER H 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 3 TOWNSHIP 10 RANGE 33 NMPM.		8. Farm or Lease Name New Mex. State
15. Elevation (Show whether DF, RT, GR, etc.) 4211.1 GR		9. Well No. 2
		10. Field and Pool, or Wildcat Vada Penn
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot a 25 sx. plug at TD to cover existing perforations.
2. Load hole with mud laden fluid,
3. Recover production casing from approximately 5000'
4. Spot a 35 sx. plug at stub of 5-1/2" casing
5. Spot a 50 sx. plug in and out of base of intermediate csg. set @ 3913'
6. Shoot and recover 8-5/8" casing from approximately 1000' & spot a 50 sx. plug.
7. Spot a 50 sx. plug in and out of base of 11-3/4" set at 320'.
8. Spot a 10 sx. top hole plug and erect a regulation marker.

(all plugs are cement)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Stanley L. Baker TITLE Agent DATE 5/16/73

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: