

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-274	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Bridwell Oil Company		8. Farm or Lease Name New Mex. 8 State
3. Address of Operator P.O. Box 2038, Abilene, Texas 79604		9. Well No. 2
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>8</u> TOWNSHIP <u>9-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat Flying "M" San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 4386 Gr.		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods and pump
2. Mix mud and load hole 2500# PER 100 bbls 9.5 brine
3. Pump cement plug 4490-4390 (Covers all perms.)
4. Pull tubing and attempt shot in casing (top of cem. 3600)
5. Pull casing
6. Run tubing and pump 100' plug in and out of cut-off pt.
7. Pump 100' plug 1700-1800' (Above salt)
8. Pump 100' plug in and out of bottom surface 300-400'
9. Place 10 sx. in top of 8 5/8 surface casing.

NOTIFY COMMISSION 24 hrs Prior to setting btm. Plug

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bruce Henry TITLE Production Superintendent DATE 11-22-74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: