

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator McMoran Exploration Company	8. Farm or Lease Name 31
3. Address of Operator 3400 Plaza Tower, New Orleans, La. 70113	9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> , <u>1980</u> FEET FROM THE <u>Norta</u> LINE AND <u>660</u> FEET FROM THE <u>Last</u> LINE, SECTION <u>31</u> TOWNSHIP <u>11S</u> RANGE <u>35E</u> NMPM.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To set cast iron plug and 35 sacks cement plug at 10,000' in 5-1/2" casing. Shoot casing approx. 4212' & pull. Set 35 sacks cement plug in and out. Set 65 sacks cement after shooting 8-5/8" at free point. Set 65 sacks cement plug at 304' in and out 13-3/8" surface. Set surface cement plug with dry hole marker.

Set 100' plug at top & bottom of salt if not behind pipe

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Wm. Sanford</u>	TITLE <u>Agent</u>	DATE <u>3/5/76</u>
Orig. Signed by <u>John Ruoyan</u> Geologist	TITLE _____	DATE <u>3/10/76</u>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		