

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-78	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> WELL CAS <input type="checkbox"/> WELL OTHER- <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Mission Exploration, Inc.		8. Farm or Lease Name Mission "6" State	
3. Address of Operator P.O. Box 2188 Hobbs, New Mexico 88240		9. Well No. 2	
4. Location of Well UNIT LETTER <u>G</u> <u>2080</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>6</u> TOWNSHIP <u>10S</u> RANGE <u>34E</u> NMPM.		10. Field and Pool, or WHcat Vada Penn	
11. Elevation (Show whether DF, RT, GR, etc.) 4260.0		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

3-16-82

- Set 200' plug across perfs. @ TD to 9685'.
- Come out of hole with tubing and pull as much 5 1/2" casing as possible.
- Pick up 2 7/8" tubing and set the following plugs.
 - 100' plug across casing stub.
 - 100' plug 5370 - 5470.
 - 100' plug 2100 - 2200.
 - 10 sx plug @ surface.
- Cut well head off and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jerry Sexton</u>	TITLE <u>NRE Agents for Mission Exploration</u>	DATE <u>3-16-82</u>
APPROVED BY <u>JERRY SEXTON</u>	TITLE <u></u>	DATE <u>MAR 22 1982</u>