

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-

5a. Indicate Type of Lease  
State ☒ Fee ☐  
5. State Oil & Gas Lease No.  
LG-5218

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Lundberg Operating Company 3. Address of Operator 545 Upper North Broadway, Suite 706, Corpus Christi, TX 78476 4. Location of Well UNIT LETTER F, 1980 FEET FROM THE N LINE AND 1980 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 9S RANGE 37E N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.) 3946.9 Ground	7. Unit Agreement Name 8. Farm or Lease Name State 36 9. Well No. 1 10. Field and Pool, or Wildcat Sawyer (San Andres) Assoc. 12. County Lea
---	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to plug well as follows:

- 1) Set 30 sx cement at top perf (4928').
- 2) Cut 5-1/2" production casing at approximately 2000' (8-5/8" surface casing set @ 2065' w/cement to surface)
- 3) Set 35 sx cement across 5-1/2" stub.
- 4) Set 10 sx cement at surface.
- 5) Rest of hole between plugs to be filled with plugging mud (10 ppg salt gel).

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>C.A. Lundberg</u>	TITLE <u>Operations Manager</u>	DATE <u>April 12, 1988</u>
APPROVED BY <u>Paul Kautz</u> Geologist	TITLE _____	DATE <u>APR 15 1988</u>
CONDITIONS OF APPROVAL, IF ANY:		