

STATE OF NEW MEXICO

ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P.O. Box 2088

SANTA FE, NEW MEXICO 87501

Form C-103

Revised 10-1-78

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No.  L-191	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT-" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name -
2. Name of Operator Read & Stevens, Inc.	8. Farm or Lease Name Belco State
3. Address of Operator P.O. Box 1518, Roswell, NM 88201	9. Well No. 1
4. Location of Well  UNIT LETTER <u>F</u> 1980 FEET FROM THE <u>North</u> LINE AND 1980 FEET FROM THE <u>West</u> LINE. SECTION <u>5</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM	10. Field and Pool, or Wildcat Flying "M" San Andres
5. Elevation (Show whether DF, RT, GR, etc.) 4500' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1) Set CIPB @ 4300'. Spot 35' of cmt on top of CIPB w/ Dump Bailer.

2) Circ hole w/ saltmud.

3) Cut casing @ 2400'. Pull casing.

4) Spot 50sx plug 1/2 in and 1/2 out of casing stub.

5) Spot 35sx plug 1750'-1650' across casing shoe.

6) Spot 10sx surface plug w/ 4"x10' Dryhole Marker.

7) Clean location and prep for inspection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Bruce Stobbs</u>	TITLE <u>Drilling &amp; Production Manager</u>	DATE <u>8-29-83</u>
APPROVED BY <u>ORIGINAL SIGNED BY JERRY SEXTON</u>	TITLE <u>DISTRICT SUPERVISOR</u>	DATE <u>AUG 31 1983</u>

THIS FORM IS TO BE FILED IN THE OFFICE OF THE DISTRICT SUPERVISOR OF OIL CONSERVATION FOR THE C-103 FORM APPROVED

RECEIVED  
AUG 30 1983  
G.C.D.  
LOCALS OFFICE