

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

## OIL CONSERVATION DIVISION

2040 Pacheco St.  
Santa Fe, NM 87505

WELL API NO. 30-025-34049
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 21059
7. Lease Name or Unit Agreement Name State 7
8. Well No. 1
9. Pool name or Wildcat Wildcat - Devonian
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3974 Gr

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Cobra Oil & Gas Corporation
3. Address of Operator P.O. Box 8206 Wichita Falls, Texas 76307-8206
4. Well Location Unit Letter <u>P</u> : <u>591</u> Feet From The <u>South</u> Line and <u>543</u> Feet From The <u>East</u> Line Section <u>7</u> Township <u>10S</u> Range <u>37E</u> NMPM <u>Lea</u> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3974 Gr

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5½" casing set to 12,532'. Completed open hole 12,532'-12,563'. Set 25 sack cement plug from 12,500'-12,300'. Cut off 5½" casing ±10,000' and pull. Set 35 sack cement plug from 9900'-10,100'. Set 25 sack cement plug from 7000'-7150'. Set 25 sack cement plug from 5000'-5150'. Set 40 sack cement plug from 4200'-4400'. Set 10 sack cement plug at surface. Cut off casing 3' below ground level and mark with steel P & A marker.

NEEDS  
SPOKE W/ RORY EDWARDS 100' PLUG @ 2329-2229 T.O.S.  
100' PLUG @ 354'-354' SHOE PLUG

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rory Edwards Jr TITLE Production Supervisor DATE 11/11/97  
TYPE OR PRINT NAME Rory Edwards TELEPHONE NO. 940 716-5100

(This space for State Use) ORIGINAL SIGNED BY CHRIS WILLIAMS  
DISTRICT I SUPERVISOR

EB 12 1998

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

JCS

dp