

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-7097</b>	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>Atlantic Richfield Company</b>		8. Farm or Lease Name <b>State "AE"</b>
3. Address of Operator <b>P. O. Box 1978, Roswell, New Mexico 88201</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>D</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>36</b> TOWNSHIP <b>8-S</b> RANGE <b>36-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Allison-Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4079' DF</b>		12. County <b>Roosevelt</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is no longer economical to produce and we propose to plug & abandon as follows:

Set DR plug in 415-D packer at 9525' and cap w/2 sx cement.  
Shoot off and recover 7" casing from free point (estimate 4500-5000').  
Set these cement plugs, leaving 2# mud between plugs.  
30 sx in and out of 7" stub.  
30 sx in and out of 9-5/8" shoe at 4183'.  
10 sx in top of well.

Erect dry hole marker. Clear and level location. 13-3/8" & 9-5/8" casing strings will remain intact.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Ed L. Litcher* TITLE Dist. Dir. Supervisor DATE 2/10/71

APPROVED BY *[Signature]* TITLE APPROVER'S DISTRICT DATE FEB 15 1971  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 12 1971

OIL CONSERVATION COMM.  
ROCKS, N. M.