

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-02915 #

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal "F"

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Prairie San Andres, South

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

21-8S-36E

12. COUNTY OR PARISH

Roosevelt

13. STATE

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

American Petrofina Co. of Texas

3. ADDRESS OF OPERATOR

Box 1311, Big Spring, TX 79720

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

(Unit D) - 660 FNL and 660 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

+4,142 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Federal "F" No. 1 - Plug & Abandon.

1. Move in casing pulling unit and 5,000' of tubing.
2. Spot 35 sx cmt plug 5,060+ to 4,600+.
3. Shoot 4-1/2" casing (with explosive) at free point - pull 4-1/2" casing.
4. Spot 35 sx cmt plug at 4-1/2" stub.
5. Shoot 8-5/8" casing at free point - pull 8-5/8" casing.
6. Using tubing spot 35 sx plug at 2,000', or at stub if below 1,000'.
7. Spot 75 sx cmt plug at 535' to 435'.
8. Set 10 sx plug at surface with metal marker.
9. Restoration of surface as per attached copy of letter to Dept. of Game and Fish.

*Plugs may be subject to change as pipe recovery proceeds.

NOTIFY USGS IN TIME TO
WITNESS PLUGGING OPERATIONS

SEE ATTACHED SHEET FOR
GENERAL PLUGGING REQUIREMENTS

18. I hereby certify that the foregoing is true and correct

SIGNED

J. C. Chapman
J. C. Chapman

(This space for Federal or State office use)

TITLE **Assistant Dist. Mgr. of
Production**

DATE **December 18, 1975**

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

*See Instructions on Reverse Side

APPROVED
AS AMENDED
DEC 29 1975
ARTHUR R. BROWN
DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE : 1963-O-685229

847 - 485

RECEIVED
FEDERAL BUREAU OF INVESTIGATION
U.S. DEPARTMENT OF JUSTICE
WASHINGTON, D.C. 20535
JAN 10 1964
FOR THE DIRECTOR
FROM THE
SAC, NEW YORK
NY 100-100000
RE NEW YORK
LETTER TO
BUREAU, JAN
10, 1964
NY 100-100000
RE NEW YORK
LETTER TO
BUREAU, JAN
10, 1964