

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-2610	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Tom L. Ingram		8. Farm or Lease Name State
3. Address of Operator POB 1757, Roswell, New Mexico 88201		9. Well No. 2
4. Location of Well UNIT LETTER E 1650 FEET FROM THE North LINE AND 990 FEET FROM West 32 TOWNSHIP 8S RANGE 38E NMPM.		10. Field and Pool, or Wildcat North Sawyer Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3972 GL		12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Verbal approval from John Runyan, NMOCC, 11/13/74

Set CIBP @ 9300 with 35' of cement on top. Set 100' plug @ stub of 5 1/2" csg. @ 4500. Set 100' plug in & out of base of 8-5/8 csg. @ 4126. Cut 8-5/8 @ approximately 1400' and pull. Set 100' plug in and out of stub of 8-5/8. Set 100' plug in and out of base of 13-3/8 @ 405. Set 10 sack plug @ surface and set marker. Mud laden brine to be used between all plugs. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Tom L. Ingram TITLE Operator DATE 11/13/74

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

NOV 14 1974

**OIL CONSERVATION COMM.
HOBBBS, H. M.**