

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
Artesia, NM 88210Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

Federal N.M. 0554778

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Champlin Petroleum Company

3. ADDRESS OF OPERATOR

300 Wilco Building Midland, TX 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FS & EL, Sec. 29, T-7-S, R-33-E

State Unit - P

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4441 DF

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Lauck-Federal

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

Chaveroo (San Andres)

11. SEC., T., R., M., OR BLE, AND
SURVEY OR AREA

Sec. 29, T-7-S, R-33-E

12. COUNTY OR PARISH 13. STATE

Roosevelt

N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

☐
☐
☐
☒
☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well uneconomical to produce.

Proposed plugging procedure.

Set CIBP @ 4100' and cap w/50' cement. Locate 4-1/2" casing free point. (Should be at approximately 1400' +). Cut off 4-1/2" OD casing at free point. Set 100' cement plug centered at top of 4-1/2" casing stub. Set 100' plug across surface casing shoe @ 409'. Set 10 sx plug in top of surface pipe with marker installed. Fluid between plugs to be 10#/gal mud.

San Andres perfs 4282'-4348'.



18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

TITLE

District Superintendent
Drilling & Prod. Opr.

DATE

7/12/83

APPROVED BY PETER W. HESTER
CONDITIONS OF APPROVAL, IF ANY

TITLE

DATE

SEP 7 1983

*See Instructions on Reverse Side

RECEIVED

SEP 8 1983

O.C.D.
HOBBS OFFICE