

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
NM 10130, NM3934, K2734

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name State 32-7-33 Unit
2. Name of Operator Champlin Petroleum Company	8. Farm or Lease Name
3. Address of Operator 300 Wilco Building Midland, TX 79701	9. Well No. 2
4. Location of Well UNIT LETTER A, 660 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 32 TOWNSHIP 7-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Chaveroo (San Andres)
15. Elevation (Show whether DF, RT, GR, etc.) 4432 GR	12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well uneconomical to produce.

Proposed plugging procedure.

Set CIBP @ 4100' and cap w/50' cement. Locate 4-1/2" casing free point. (Should be at approximately 1400' +). Cut off 4-1/2" casing at free point. Set 100' cement plug centered at top of 4-1/2" casing stub. Set 100' plug across surface casing shoe @ 407'. Set 10 sx plug in top of surface pipe with marker installed. Fluid between plugs to be 10#/gal mud.

San Andres Perfs 4252'-4342'

THE COMMISSION MUST BE NOTICED 24 HOURS AHEAD TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CIBP TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED K. W. L... TITLE District Superintendent DATE 7/14/83
Drilling & Prod. Operations

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE JUL 28 1983