

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPI
(Other instructions
reverse side)FE-
re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-010650

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Roland McLean Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Todd Lower San Andres

11. SEC., T., R., M., OR BLK. AND

SURVEY OR AREA
Sec. 23, T-1-R,
R-35-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Texaco Inc.	8. FARM OR LEASE NAME Roland McLean Federal
3. ADDRESS OF OPERATOR P. O. Box 20, Hobbs, New Mexico 88240	9. WELL NO. 2
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below) At surface 990' FSL and 990' FWL of Section 23, T-1-R, R 35 E, Unit Letter M.	10. FIELD AND POOL, OR WILDCAT Todd Lower San Andres
14. PERMIT NO. Regular	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4199' GR
12. COUNTY OR PARISH Roosevelt	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Pull production equipment.
2. Mud up hole, spot 150' (22 sq.) cement plug across perfs. (4095-4220).
3. Pull tubing, run free point indicator, cut 4-1/2" casing and pull same. (Calculated cement top @ 3500').
4. Run tubing, spot 100' (35 sq.) cement plug across interval where casing was cut.
5. Pull up, spot 100' (35 sq.) cement plug across 4-5/8" casing shoe @ 243' (50' above and 50' below).
6. Spot 10 sq. cement plug @ surface, install marker and clean location.

AMENDMENT: Step 2: This plug should be 25 sacks minimum and top of plug should be at least 100 feet above top perforation.

Step 4: If 4 1/2" csg. is cut and pulled from below 2,000 feet place additional 100 foot cement plug in the interval 1900-2000 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Asst. Dist. Supt.

DATE

10-17-73

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
OCT 24 1973
R. BROWN

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.