

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

Nov 29 9 55 AM '65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8946
7. Unit Agreement Name
8. Farm or Lease Name Atlantic State
9. Well No. 1
10. Field and Pool, or Wildcat Undesignated
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry hole
2. Name of Operator W. G. Smith, Jr.
3. Address of Operator c/o Ernest A. Hanson, P. O. Box 1515, Roswell, New Mexico
4. Location of Well UNIT LETTER G 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 32 TOWNSHIP 7-S RANGE 35-E NMPM.
15. Elevation (Show whether DF, AT, GR, etc.) 4234' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIATION WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

4-1/2" csg. set @ 4559' w/250 sx. Perfs. @ 4380-4537'. PBSD @ 4559'.

Permission to plug and abandon the captioned well in the following manner is hereby requested:

1. Set a 25 sx. cmt. plug from 4559' to 4239' across all perfs.
2. Establish a free-point and pull all 4-1/2" csg. possible.
3. Fill hole with heavy mud.
4. Set a 25 sx. cmt. plug at the stub of the shot-off 4-1/2" csg.
5. Set a 25 sx. cmt. plug at the 8-5/8" shoe-joint @ 247'.
6. Set a 10 sx. cmt. plug at the surface & erect a regulation dry-hole marker.
7. Clean up the location for inspection by the NMOCC.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Harry F. Schuman</i></u>	TITLE <u>Agent</u>	DATE <u>Nov. 23, 1965</u>
APPROVED BY <u></u>	TITLE <u>District W</u>	DATE <u>Nov 29 1965</u>
CONDITIONS OF APPROVAL, IF ANY:		