

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. State Oil & Gas Lease No.
2. Name of Operator Gene Milford dba Milford Pipe & Supply		7. Unit Agreement Name
3. Address of Operator Box 422 Tatum, N.M.		8. Farm or Lease Name Bradley
4. Location of Well UNIT LETTER N , 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 24 TOWNSHIP 7-S RANGE 33-E NMPM.		9. Well No. 1
15. Elevation (Show whether DF, RT, GR, etc.)		10. Field and Pool, or Wildcat Chaveroo San Andres
12. County Roöbevelt		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug & Abandon as follows:

3-11-74

1. Set Cas Iron Bridge Plug @ Appx 4100' & Dump Cement to 4065'
2. Set 100' Cement plug @ 4 1/2" Csg. Stub
3. Set 100' Cement plug @ Top of Salt Section if exposed
4. Set 100' Cement plug in and out of surface csg.
5. Set 10 Sacks cement plug @ surface & install dry hole marker

Note: All plugs will be set with, and hole circulated with mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Milford TITLE Owner DATE 3-11-74

APPROVED BY Joe D. Ramsey TITLE Supv. DATE

CONDITIONS OF APPROVAL, IF ANY: None