

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Feb 17 3 27 PM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
Fee	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- DRY HOLE		7. Unit Agreement Name
2. Name of Operator TEXACO Inc.		8. Farm or Lease Name Flats Unit
3. Address of Operator P. O. Box 728 - Hobbs, N. M.		9. Well No. 1
4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1945 FEET FROM THE East LINE, SECTION 28 TOWNSHIP 8-S RANGE 34-E NMPM.		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4298' (D. F.)		12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Total Depth - 10,000'
4 1/2" O. D. Casing Cemented at 4850'

We propose to plug and abandon subject well as follows:

1. Squeeze perforations 4678' to 4714' with 100 Sx. cement.
2. Squeeze perforations 4598' to 4636' with 100 Sx. cement.
3. Cut off 4 1/2" O. D. Casing at approximately 3150', and recover same.
4. Spot 35 Sx. cement plug from 3100' to 3200', (Top of 4 1/2" Casing).
5. Spot 20 Sx. cement surface plug.
6. Clean the location as per the NMOC regulations, install 4" marker extending 4' above ground level, plug & abandon to be completed on or about Feb. 25, 1966.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dan Gillett TITLE Assistant District Superintendent DATE Feb. 17, 1966

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: