

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5. State Oil & Gas Lease No.
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole - Plug and Abandon		6. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Tom L. Ingram		7. Unit Agreement Name
3. Address of Operator P. O. Box 1757 - Roswell, New Mexico		8. Farm or Lease Name Carter
4. Location of Well UNIT LETTER E 1650 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 28 TOWNSHIP 8-S RANGE 35-E N.M.P.M.		9. Well No. 1
15. Elevation (Show whether DF, RT, GR, etc.) 4197 GL		10. Field and Pool, or Wildcat Undesignated Milnesand
12. County Roosevelt		

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set 25 sack plug over perforations 4711-4796. Cut 4-1/2" casing at 3800'. Spot 25 sack plug in and out of stub. Set 25 sack plug at base of salt at 2650. Set 25 sack plug at top of the salt at 2250. Set 25 sack plug at base of 8-5/8" at 390. Set 10 sack plug at surface. Mud will be used between each plug. Set marker and cleared location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Tom L. Ingram TITLE Operator DATE October 17, 1966

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: