

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

CORRECTED REPORT
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator		8. Farm or Lease Name	
Southwestern Natural Gas, Inc.		Jones "26"	
3. Address of Operator		9. Well No.	
900 Building of the Southwest - Midland, Texas 79701		2	
4. Location of Well		10. Field and Pool, or Wildcat	
UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM		Chaveroo San Andres	
THE <u>West</u> LINE, SECTION <u>26</u> TOWNSHIP <u>7-S</u> RANGE <u>32-E</u> NMPM.			
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
4440' GR		Roosevelt	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods, Pump & Tbg.
2. Spot 25 sacks cement plug across perf. interval.
3. Determine free point of csg. & shoot csg. off.
4. Pull csg.
5. Spot 25 sacks cement plug 50' in & out of csg. stub.
6. Spot 25 sacks cement plug 1650' - 1750' (surf. csg. shoe).
7. Spot 10 sacks cement plug in surface.
8. Remove wellhead & weld steel plate on surface csg.
9. Install dry hole marker.
10. Clean location.

Work to be started on approval of application.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don C. Bennett TITLE Operations Manager DATE October 29, 1969
APPROVED BY [Signature] TITLE [Signature] DATE [Signature]
CONDITIONS OF APPROVAL, IF ANY: