

NEW MEXICO OIL CONSERVATION COMMISSION

Form O-111
Revised 1-1-74
and 1-1-75
Effective 1-1-74

Oil Well Drilling Permit

State NM

State Oil & Gas Department

SUNDRY NOTICES AND REPORTS ON WELLS

NOTE: USE THIS FORM FOR PROPOSALS TO DRILL OR TO CLEAN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT FORM (FORM O-101) FOR SUCH PROPOSALS.

1. Well No. <u>1930</u>	2. Gas Well ☐ Other ☐	3. Well Name <u>Cabot State</u>
4. Operator <u>Roger C. Hanks Oil Company</u>	5. Well No. <u>2</u>	6. Well Name <u>Cabot State</u>
7. Location <u>c/o Hobbs Pipe & Supply, Box 2010, Hobbs, N. M. 88240</u>	8. Well No. <u>2</u>	9. Well Name <u>Cabot State</u>
10. Direction <u>I</u> <u>1930</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>8 S</u> RANGE <u>36 E</u> N.M.P.M.	11. Direction <u>I</u> <u>1930</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>8 S</u> RANGE <u>36 E</u> N.M.P.M.	12. Direction <u>I</u> <u>1930</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>8 S</u> RANGE <u>36 E</u> N.M.P.M.
13. Elevation (Show whether DF, RT, GR, etc.) <u>4104 GR</u>	14. County <u>Roosevelt</u>	15. County <u>Roosevelt</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPERATIONS ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

16. Describe proposed or completed operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. SEE RULE 1103.

1. Spot a 20 sx cement plug across existing perforations.
2. Load hole w/mud-laden fluids.
3. Cut & pull 5-1/2" casing.
4. Spot a 35 sx cement plug across 5-1/2" casing stub.
5. Spot a 35 sx cement plug @ top of Clorietta, 5500'.
6. Spot a 35 sx cement plug across 8-5/8" casing shoe @ 4090'.
7. Cut & pull 8-5/8" casing.
8. Spot a 75 sx cement plug across 8-5/8" casing stub.
9. Spot a 75 sx cement plug across 13-3/8" casing shoe @ 400'.
10. Spot a 10 sx surface plug and erect a 4" regulation marker.

13 3/8" set at 400' Cemented w/ 450 SX
8 5/8" set @ 4090' w/ 370 SX Cement
Hole size 15"
11"

17. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED S. Saitkin TITLE AGENT DATE 3/1/74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: