

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-041-20412
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Murphy Hinton
8. Well No. 1
9. Pool name or Wildcat Bluitt San Andres, Assoc.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
2. Name of Operator John A. Yates, Jr. - Oil Operator
3. Address of Operator 105 South 4th St., Artesia, NM 88210
4. Well Location Unit Letter <u>A</u> : <u>660</u> Feet From The <u>North</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>22</u> Township <u>8S</u> Range <u>37E</u> NMPM <u>Roosevelt</u> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4008' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: Abandon existing San Andres perfs & add new perfs in San Andres <input checked="" type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
Propose to abandon existing perforations 4753-4847' (San Andres) and add new perforations in San Andres as follows:

1. POOH with rods, pump and tubing.
2. TIH with casing scraper and 2-7/8" tubing to 4720'. TOOH.
3. TIH with CIBP and set CIBP at 4710' to abandon perforations 4753-4847' (San Andres). Cap CIBP at 4710' with 35' of cement.
4. Perforate 4094-4606' (San Andres), acidize as necessary for production.
5. Swab test.
6. Place well into production.

If workover attempt is not successful, will plug and abandon as follows:

1. POOH with tools and tubing.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CONTINUED ON NEXT PAGE:

SIGNATURE Rusty Klein TITLE Operations Technician DATE April 28, 2000
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: