

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-041-20617
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name State (SWD)
8. Well No. #1
9. Pool name or Wildcat Tucker Ranch SWD, SA
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4400' G. L.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER SWD
2. Name of Operator Devon Energy Company (Nevada)
3. Address of Operator 20 North Broadway Suite 1500 Oklahoma City, OK 73102
4. Well Location Unit Letter B : 660' Feet From The north Line and 1980' Feet From The east Line Section 16 Township 7S Range 33E NMPM Roosevelt County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4400' G. L.

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug and abandon this SWD well as follows: *

1. Set a CIBP above the perfs at 3867' - 3874' and dump 35' of cement on top.
2. Set a 100' cement plug at 1335'.
3. Set a 10 sx cement plug at surface.
4. After setting the required plugs, load the hole with 10# brine + 25#/bbl gel.

Set CIBP THEN LOAD HOLE w/ mud

*NOTE: This well has 8 5/8" casing set at 3922'.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debby O'Donnell TITLE Engineering Technician DATE 10/19/93
TYPE OR PRINT NAME Debby O'Donnell TELEPHONE NO. (405) 552-4511

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE OCT 25 1993

CONDITIONS OF APPROVAL, IF ANY: