

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division  
1625 N. French Dr.  
Hobbs, NM 88240

FORM APPROVED  
Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT-" for such proposals

Case Designation and Serial No.  
NM-36486

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE

1. Type of Well

Oil Gas  
☒ Well ☐ Well ☐ Other

2. Name of Operator

STRATA PRODUCTION COMPANY

3. Address and Telephone No.

P. O. Box 1030  
Roswell, New Mexico 88202-1030 505-622-1127

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 620' FWL  
Section 31-7S-32E

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Gallina Federal #1

9. API Well No.

30-041-20702

10. Field and Pool, or Exploratory Area

Tomahawk San Andres

11. County or Parish, State

Roosevelt County, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ OTHER

☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Strata Production Company requests approval to plug and abandon the well in the following manner:

1. Set CIBP at 4100' and cap with 25 sacks cement.
2. Cut casing at 3100'. Set 25 sack cement plug half in-half out of stub at 3050'-3150'. TAG
3. Set 25 sack cement plug at 2100'-2200'.
4. Set 25 sack cement plug at 1700'-1800'. TAG
5. Set 10 sack cement plug at 30' to surface.
6. Set Dry Hole Marker and finalize location.

SEE ATTACHED FOR  
CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct

Signed Carol J. Garcia

Title Production Records Manager Date 5/18/00

(This space for Federal or State office use)

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA Title

PETROLEUM ENGINEER

Date MAY 23

Conditions of approval, if any:

GWV