

Form 9-331  
(May 1963)UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPI  
(Other instructions  
verse side)FE-  
re-Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

NM-0338-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

None

7. UNIT AGREEMENT NAME

Little Lucky Lake Unit

8. FARM OR LEASE NAME

Peery-Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Little Lucky  
Lake (Devonian)11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREASec. 29, T-15-S,  
R-30-E, (Unit Letter K)

12. COUNTY OR PARISH 13. STATE

Chaves

N.M.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)

At surface

Well is located 1820' from the South Line and 2140' from the  
West Line of Section 29, T-15-S, R-30-E, Unit Letter K, Chaves  
County, New Mexico.

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, OR, etc.)

3953' (D. F.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

We propose to do the following work on subject well:

1. Pull tubing and packer.
2. Set RBP @ 5750' and spot 100# sand on plug.
3. Set RTTS tool @ 5685'.
4. Squeeze w/100 sx. class C Cement.
5. Drill out cement and test. Pull RBP.
6. Run 2 3/8" od tubing w/packer and set @ 10,950'.
7. Acidize w/6000 gals. 28% acid and follow w/6000 gals. fresh water.
8. Pull tubing, install pump equipment, test, and return to production.

RECEIVED

DEC-3 1968

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Assistant

District Superintendent

DATE December 2, 1968

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side