

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SALE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p>
<p>1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection</p>		<p>5. State Oil & Gas Lease No.</p>
<p>2. Name of Operator Miller & Miller Auctioneers, Inc.</p>		<p>7. Unit Agreement Name Eastcap Queen/</p>
<p>3. Address of Operator</p>		<p>8. Farm or Lease Name</p>
<p>4. Location of Well UNIT LETTER B, 330 FEET FROM THE North LINE AND 2310 FEET FROM THE East LINE, SECTION 3 TOWNSHIP 15 South RANGE 31 East NMPM.</p>		<p>9. Well No. 65-2</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.)</p>		<p>10. Field and Pool, or Wildcat Caprock Queen</p>
<p>12. County Chaves</p>		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Program: Set bridge plug above perforations and cap with 35' cement. Mud hole. Cut off 5 1/2" casing. Place 100' cement plug at top of stub. If stub is below top of salt, place 100' cement plug at top of salt. Place 100' cement plug to straddle bottom of 8 5/8" casing. Cap with 10 sacks of cement. Notify Oil Commission ~~at start of operation~~ **24 hrs. before setting bottom plug.**

All cement plugs must be spotted through tubing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE Vice President	DATE 10-14-74
APPROVED BY <i>[Signature]</i>	TITLE <i>[Signature]</i>	DATE

CONDITIONS OF APPROVAL, IF ANY:
12/