

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-10416	
7. Unit Agreement Name	
North Caprock Queen Unit 2	
8. Farm or Lease Name	
Tract #3	
9. Well No.	
#1	
10. Field and Pool, or Wildcat	
Caprock Queen	
12. County	
Chaves	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection	2. Name of Operator
	Biden-Sumner-Sumner Anadarko Production Co.
3. Address of Operator	4. Location of Well
P.O. Box 647 Artesia, New Mexico 88210	UNIT LETTER J , 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 1 TOWNSHIP 13-S RANGE 31-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)	16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
4390 GL	NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows:

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 4 1/2" liner approximately 3000'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knock off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing cut off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

*25 3x3 in + out of surface csg. shoe
Heavy mud between all plugs*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE Secretary	DATE 10-28-71
APPROVED BY <i>[Signature]</i>	TITLE SUPERVISOR DISTRICT I	DATE NOV 8 1971
CONDITIONS OF APPROVAL, IF ANY:		