

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>B-10416</b>	

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
<del>Western Supply Company</del> <b>Anadarko Production Company</b>		<b>Tract #4</b>
3. Address of Operator		9. Well No.
<b>P.O. Box 647 Artesia, New Mexico 88210</b>		<b>#1</b>
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <b>F</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM		<b>Caprock Queen</b>
THE <b>West</b> LINE, SECTION <b>1</b> TOWNSHIP <b>13-S</b> RANGE <b>31-E</b> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
<b>4402 GL</b>		<b>Chaves</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 103

**Intend to plug and abandon well as follows**

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 4 1/2" liner approximately 3020'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knoc. off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing cut off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

*25 sacks in & out of surface using shoe  
Heavy mud between all plugs*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE **Secretary** DATE **10-28-71**

APPROVED BY *[Signature]* TITLE **SUPERVISOR DISTRICT I** DATE **NOV 8 1971**

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

NOV 10 1971

OIL COMPANY  
10000