

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p> <p>5. State Oil & Gas Lease No. B-10420</p>
<p>1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection</p> <p>2. Name of Operator Anadarko Production Company</p> <p>3. Address of Operator P. O. Box 67, Loco Hills, New Mexico 88255</p> <p>4. Location of Well UNIT LETTER C, 330 FEET FROM THE North LINE AND 1650 FEET FROM THE West LINE, SECTION 1 TOWNSHIP 13-S RANGE 31-E NMPM.</p>	<p>7. Unit Agreement Name North Caprock Queen Unit 2</p> <p>8. Farm or Lease Name Tract #3</p> <p>9. Well No. #2</p> <p>10. Field and Pool, or Wildcat Caprock Queen</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.) 4403</p>	<p>12. County Chaves</p>	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows:

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 5½" casing approximately 3000'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Set 10 sack cement plug at surface.
5. Set surface marker.
6. Remove all equipment and clean up location.

No casing will be pulled from well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>D. R. Leyton</i></u> D. R. Leyton	TITLE <u>District Superintendent</u>	DATE <u>Sept. 8, 1971</u>
APPROVED BY _____	TITLE <u>Mr. D. Ramsey</u> Dist. I, Supv.	DATE <u>SEP 13 1971</u>

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 1 1971

OIL CONSERVATION COMM.
HOUSTON, TEX.