

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-9541

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection	7. Unit Agreement Name North Caprock Queen Unit 2
2. Name of Operator Midco Energy Co., Inc. Anadarko Production Co.	8. Farm or Lease Name Tract #28
3. Address of Operator P.O. Box 647 Artesia, New Mexico 88210	9. Well No. #1
4. Location of Well UNIT LETTER P , 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 2 TOWNSHIP 13-S RANGE 31-E N.M.P.M.	10. Field and Pool, or Wildcat Caprock Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4400 GL	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows:

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 7" casing approximately 2980'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knock off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing cut off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

*25 sacks in & out of surface casing shoe
Heavy mud between all plugs*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE Secretary agent	DATE 10-28-71
APPROVED BY <i>[Signature]</i>	TITLE SUPERVISOR DISTRICT I	DATE NOV 8 1971
CONDITIONS OF APPROVAL, IF ANY: <i>10 3/4" set @ 298' 6 5/8" 30 11</i>		

RECEIVED

DEC 8 1971

OIL CONSERVATION COMM.
HOODS, L. L.