

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
<b>B-8631</b>

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>	7. Unit Agreement Name
2. Name of Operator	<b>North Caprock Queen Unit 2</b>
<del>XXXXXXXXXXXXXXXXXXXX</del> <b>Anadarko Production Co.</b>	8. Farm or Lease Name
3. Address of Operator	<b>Tract #27</b>
<b>P.O. Box 647</b> <b>Artesia, New Mexico 88210</b>	9. Well No.
4. Location of Well	<b>#3</b>
UNIT LETTER <b>P</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM	10. Field and Pool, or Wildcat
THE <b>East</b> LINE, SECTION <b>11</b> TOWNSHIP <b>13-S</b> RANGE <b>31-E</b> NMPM.	<b>Caprock Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
<b>4412 GL</b>	<b>Chaves</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows :

1. Pull tubing. (Old packer hung in 4½" liner at 1850'.)
2. Set cast iron cement retainer in 7" casing at 1800'; Above top of 4½" liner at 1820', and pump 50 sack cement plug below retainer, pick up and spot 10 sack plug on top of retainer.
3. Knock off oil string at approximately 1200' at free point.
4. Set 25 sack cement plug at casing out off point.
5. Set 10 sack cement plug at surface.
6. Set surface marker.
7. Remove all equipment and clean up location.

*25 SXS in & out of surface csg. shoe*  
*Heavy mud between all plugs*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE <b>Secretary Agent</b>	DATE <b>10-28-71</b>
APPROVED BY <i>[Signature]</i>	TITLE <b>SUPERVISOR DISTRICT I</b>	DATE <b>NOV 8 1971</b>
CONDITIONS OF APPROVAL, IF ANY: <b>10 3/4" set @ 320'</b> <b>7" @ 3028'</b>		

RECEIVED

NOV 6 1971

OIL CONSERVATION COMM.  
U.S. DEPT. OF THE INTERIOR