

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>R-7878</b>
7. Unit Agreement Name <b>North Caprock Queen Unit 2</b>
8. Farm or Lease Name <b>Tract #24</b>
9. Well No. <b>#1</b>
10. Field and Pool, or Wildcat <b>Caprock Queen</b>
12. County <b>Chaves</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	2. Name of Operator <b>Anadarko Production Co.</b>
3. Address of Operator <b>P.O. Box 647 Artesia, New Mexico 88210</b>	4. Location of Well UNIT LETTER <b>M</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>12</b> TOWNSHIP <b>13-S</b> RANGE <b>31-E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>4398 GL</b>	16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.



### Intend to plug and abandon well as follows:

1. Pull tubing and rods.
2. Set cast iron bridge plug at base of 4 1/2" liner approximately 3010'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knock off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing out off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

~~No casing will be pulled from well.~~

25 sacks in & out of surface csq. shoe  
Heavy mud between all plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE <b>Secretary Agent</b>	DATE <b>10-28-71</b>
APPROVED BY 	TITLE <b>SUPERVISOR DISTRICT I</b>	DATE <b>NOV 8 1971</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAY 6 1971

OIL CONSERVATION COMM.  
WASHINGTON, D. C.