

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-10417-5
7. Unit Agreement Name North Caprock Queen Unit 2
8. Form of Lease Name Tract #16
9. Well No. #1
10. Field and Pool, or Wildcat Caprock Queen
12. County Chavez

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection
2. Name of Operator Anadarko Production Co.
3. Address of Operator P.O. Box 647 Artesia, New Mexico 88210
4. Location of Well UNIT LETTER F , 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 12 TOWNSHIP 13-S RANGE 31-2 NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4400CL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	
ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows:

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 4 1/2" casing approximately 3010'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knock off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing cut off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

~~No casing will be pulled from well.~~

*25x5 in & out of surface casing shoe
Heavy mud between all plugs*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE Secretary Agent	DATE 10-28-71
APPROVED BY <i>[Signature]</i>	TITLE SUPERVISOR DISTRICT I	DATE NOV 8 1971
CONDITIONS OF APPROVAL, IF ANY: 9 5/8" 34# set at 276' 7" 22# 3033'		

RECEIVED

DEC 6 1971

OIL CONCENTRATION CO. INC.
LAWSON, ARIZ.