

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

HOBBS OFFICE O.C.C.
NEW MEXICO OIL CONSERVATION COMMISSION

MAR 8 11 31 AM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E - 7713	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- Injection Well		7. Unit Agreement Name North Central Caprock Queen Unit
2. Name of Operator Great Western Drilling Company		8. Farm or Lease Name
3. Address of Operator Box 1659, Midland, Texas		9. Well No. #12
4. Location of Well UNIT DEEPER L 1980 FEET FROM THE South LINE AND 660 FEET FROM West LINE, SECTION 13 TOWNSHIP 13-S RANGE 31-E NMPM.		10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4410 GR.		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
REEL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The hole will be loaded with mud. Great Western Drilling Co. plans to set a 25 sack cement plug @ 3050' (which is above perforations 3051-63) and fill casing to 2875', pull some 1000' of 5-1/2", place a 25 sack plug in the stub, 25 sacks at the surface pipe shoe with 5 sacks at the surface. A proper marker will be placed and cleanup made. Starting date as soon as possible.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C.H. Crews TITLE Administrative Coordinator DATE March 7, 1966

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: