

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. -
7. Unit Agreement Name D. Q. S. U.
8. Farm or Lease Name Tract 19
9. Well No. 1
10. Field and Pool, or Wildcat Caprock Queen
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Cities Service Oil Company
3. Address of Operator Box 69 - Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER K 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 14S RANGE 31E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4400 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well in the following manner:

1. Set CI bridge plug in casing just above open hole.
2. Set 2 sack cement plug on top of bridge plug.
3. Load hole with mud laden fluid.
4. Cut and pull approx. 2000' of 7" casing.
5. Set 100' cement plug, $\frac{1}{2}$ in and $\frac{1}{2}$ out of 7" casing stub.
6. Set 100' cement plug at the top of the salt section.
7. Set 100' cement plug, $\frac{1}{2}$ in and $\frac{1}{2}$ out of 13 3/8" surface casing stub.
8. Set 10 sack cement surface plug with a 4' dry hole marker.
9. Clean location of all debris and equipment.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE **District Admin. Supervisor** DATE **March 26, 1970**

APPROVED BY John W. Runyan TITLE _____ DATE **3/27/70**

CONDITION OF APPROVAL, IF ANY:

OL CONSERVATION 99/M.
HOBBS, N. H.

MAR 27 1970

RECEIVED