

OF COPIES RECEIVED		
DISTRIBUTION		
STATE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection		7. Unit Agreement Name Eastcap Queen
2. Name of Operator Miller & Miller Auctioneers, Inc.		8. Farm or Lease Name
3. Address of Operator		9. Well No. 33
4. Location of Well UNIT LETTER <u>O</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14 South</u> RANGE <u>31 East</u> NMPM.		10. Field and Pool, or Wildcat Caprock Queen
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Program: Set bridge plug above 3092' and cap with 35' cement. Mud hole. Cut off 5-1/2" casing. Place 100' cement plug at top of stub. If stub is below top of salt, place 100' cement plug at top of salt. Place 100' cement plug to straddle bottom of 8-5/8" casing. Cap with 10 sacks of cement. Notify Oil Commission ~~at~~ 24 hrs ~~start of operations~~ before setting bottom plug.

All cement plugs must be spotted through tubing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>[Signature]</u>	TITLE <u>Vice President</u>	DATE <u>10-14-74</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>[Signature]</u>	DATE <u> </u>
CONDITIONS OF APPROVAL, IF ANY:		