

COPIES RECEIVED	
TRIBUTION	
FE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☐

5. State Oil & Gas Lease No.
E 8251

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Jim Conine Inc.	8. Farm or Lease Name McAlister B
3. Address of Operator 402 First National Bank Bldg. Midland, Tex.	9. Well No. 1
4. Location of Well UNIT LETTER L 660' FEET FROM THE West LINE AND 2130 FEET FROM THE South LINE, SECTION 28 TOWNSHIP 8 S RANGE 33 E NMPM.	10. Field and Pool, or Wildcat Tobac-Penn
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose To PMA as follows:

1. Spot 25 Sk Cement Plug @ 8943' Perfs fr 9069 - 9078.
2. Cut and Pull 4 1/2" Casing Est. 6000'.
3. Run Tubing to 4 1/2" Csg. stub - Spot 40 sk Plug.
4. Spot 40 Sk Plug @ 5300' top of Gloretta.
5. Spot 40 sk Plug @ 3670' - 50' below 8 5/8" Shoe @ 3620'.
6. Cut & Pull 8 5/8" Csg. Est 1250'
7. Run tubing & spot 65 sk Plug @ 8 5/8" Stub.
8. Spot 75 Sk Plug @ 430' - 50' below 13 3/8" shoe @ 380'
9. Place 10 Sk Plug in Surface - Set Dry Hole Marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>Robert J. Janel</i>	TITLE <i>Agent</i>	DATE <i>4-29-74</i>
APPROVED BY <i>J. J. Himes</i>	TITLE <i>SUPERVISOR DISTRICT I</i>	DATE <i>10/1/74</i>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAY 1 1972

OIL CONSERVATION COMM.
ROBBS, H. L.