

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

3cc: NMOCC
CC: File

APR 18 11 34 AM '67

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Tidewater State Com.
9. Well No. 1
10. Field and Pool, or Wildcat Tobac Farm
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	
2. Name of Operator TIDEWATER OIL COMPANY	
3. Address of Operator P. O. Box 249, Hobbs, New Mexico 88240	
4. Location of Well UNIT LETTER H , 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 31 TOWNSHIP S-8 RANGE 33-E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 4384.7' GR	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	SUBSEQUENT REPORT OF: ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon this well as follows:

Lay 25 sacks cement plug over Penn perforations at 9200 - 9208. Lay 25 sacks cement plug across top of 4-1/2" stub, 25 sack plugs at top of Glorieta formation at approximately 5020' in and out of bottom of 8-5/8", across top of salt at approximately 1870', in and out bottom of 13-3/8" and 10 sack cement plug at surface. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. J. Wade TITLE Area Superintendent DATE 4-14-67

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: