

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
06-6006	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Exxon Corporation	8. Farm or Lease Name Tobac State Oil Com.
3. Address of Operator Box 1600, Midland, Texas 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>21</u> TOWNSHIP <u>8-S</u> RANGE <u>33-E</u> N.M.P.M.	10. Field and Pool, or Wildcat Tobac Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3993	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull production equipment.
2. Set CIBP at 4250' capped w/35' cmt (3 SX)
3. Cut 4 1/2" csg at freepoint 4060'
4. Set 15 SX cmt plug, 75' above and 75' below csg cut.
5. Set 15SX cmt plug top of plug 3546', bot 3696'.
6. Set 15SX cmt plug top of plug 1325', bot 1475'.
7. Set 15SX cmt plug top of plug 330', bot 405'.
8. Set 10' cmt plug at surface.
9. Install dry hole marker as required by NMOCC.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. H. Lane</u>	TITLE <u>Sr. Administrator</u>	DATE <u>8-11-81</u>
Orig. Signed by Jerry Sexton	TITLE	DATE
APPROVED BY <u>Don L. Smith</u>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		