

Form 1-5-61
(May 1960)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP LITH.
(Other instructions on re-
verse side)Form approved.
Budget Control No. 42 R14245. LEASE DESIGNATION AND SERIAL NO.
NY-0346362-A
6. IF INDIAN, ALLOTTEE OR TRUST LAND

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER <u>Zone Depleted</u>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR AMERICAN PETROLEUM CORPORATION	8. FARM OR LEASE NAME WILCOX FEDERAL
3. ADDRESS OF OPERATOR BOX 60, HOLDS, N. M. 88440	9. WELL NO.
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FSL = 660' FEL Sec 2 (Unit 7, SE 1/4 SE 1/4)	10. FIELD AND POOL, OR EQUIVALENT CRTO SAN ANDRES
14. PERMIT NO.	11. SEC. T. R. & S. OF LAND AND SURVEY OR AREA 21-5-30 NMPM
15. ELEVATIONS (Show whether DP, RT, GS, etc.) 4145' R.D.B.	12. COUNTY OR PARISH 13. STATE CHABES N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log forms.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of start, or any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Well has ceased to produce commercial quantities of oil or gas. Propose to plug and abandon as follows:

Spot 25 ex plug 3483-3100' (PERFS 3484-3486)
Shoot & pull 4 1/2" casing from free point (approx. 1300'-2000')
Spot 200 ex cement plug in & out of 4 1/2" tubing.
" " " " " " 6. 8 1/2" set 3 200'.
" 10 ex " " @ surface and erect P+A marker.
Make final cleanup and restore ground to contour.
Casing intervals filled w/ heavy mud (heavy fluid)

RECEIVED
JAN 22 1969
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO
JAN 24 1969
O. C. C.
ARTESIA, OFFICE

TE- 3596
FLD- 3484
4 1/2" Casing (set top 1300-2000')
8 1/2" Casing (set 3 200')

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

AREA SUPERINTENDENT

DATE

(This space for Federal or State office use)

DISTRICT ENGINEER

APPROVED BY

TITLE

DATE

COPIES OF APPROVAL, IF ANY:

JAN 23 1969