

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. OG-2273

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name -----
2. Name of Operator Western States Producing Company	8. Farm or Lease Name Arco-State
3. Address of Operator 900 Building of the Southwest Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>north</u> LINE AND <u>1980</u> FEET FROM THE <u>east</u> LINE, SECTION <u>4</u> TOWNSHIP <u>8-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat Chaveroo
15. Elevation (Show whether DF, RT, GR, etc.) 4416' G.L.	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: *See note PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Spot ²⁵ sacks of cement plug from 4238' back to 3970' in 4 1/2" casing.
 - Free point 4 1/2" casing and cut off at approximately 3900'. Spot 25 sack plug at at cut off point.
 - Spot 50 sack cement plug from 381' back to 261' in 8 5/8" casing.
 - Spot ¹⁰ sack cement plug at surface.
 - Remove head and weld on plate.
 - Clean location and set marker.
- * Producing perforations: 4251-4379'. No other perforations.

24 hr. notice

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don C. Bennett TITLE Operations Manager DATE April 11, 1972

APPROVED BY Joe D. Ramsey TITLE Dist. I, Supv. DATE APR 13 1972

CONDITIONS OF APPROVAL, IF ANY: