

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
1625 N. French Dr.
Hobbs, NM 88240

FORM APPROVED
Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

JOHN BOB STEARNS

3. Address and Telephone No.

PO BOX 988 CROSSROADS, NM 88144 (505) 675-2356

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL, 660' FEL, SEC 17, T8S, R31E

5. Lease Designation and Serial No.

NM 067707

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

FEDERAL TM #1

9. API Well No.

30-005-202613

10. Field and Pool, or Exploratory Area

SIETE SAN ANDRES

11. County or Parish, State

CHAVES

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

SET A CAST IRON BRIDGE PLUG ABOVE PERFORATIONS AT 3660' (PERFORATIONS 3712-3752') DUMP 35' CEMENT IN HOLE WITH A DUMP BAILER. TAG CEMENT. RUN IN HOLE WITH TUBING TO 3605'. DISPLACE HOLE WITH 10.5% FLUID. PULL UP TO 1400' SPOT 25 SACKS OF CEMENT. TAG CEMENT. PULL UP TO 1000' SPOT 25 SACKS OF CEMENT. TAG CEMENT. PERFORATE 4 1/2" CASING WITH 4 SQUEEZE HOLDS. 50' BELOW CEMENT. TAG CEMENT. PERFORATE 4 1/2" CASING AT 3141' SQUEEZED 4 1/2" CASING TO 200' WITH 4 1/2" ADI PACKER WITH 50 SACKS (TOP) SURFACE PIPE. RUN IN HOLE TO 200' WITH 4 1/2" ADI PACKER WITH 50 SACKS OF CEMENT. TAG CEMENT. RUN IN HOLE WITH 60' TUBING SPOT 10 SACKS CEMENT. INSTALL DRY HOLE MARKER. CLEAN UP LOCATION.

40 x 20 shoe

14. I hereby certify that the foregoing is true and correct

Signed

Gary Gourley

Title

AGENT

Date

5/2/01

(This space for Federal or State office use)

(ORIG. SGD.) GARY GOURLEY

Title

PE

Date

5/07/01

Approved by
Conditions of approval, if any:

RECEIVED
MAY 04 2001
BLM
ROSWELL, NM

