

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SAFETY	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name Eastcap Queen
8. Farm or Lease Name
9. Well No. 36
10. Field and Pool, or Wildcat Caprock Queen
12. County Chaves

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Miller & Miller Auctioneers, Inc.
3. Address of Operator
4. Location of Well UNIT LETTER P 990 FEET FROM THE East LINE AND 990 FEET FROM THE South LINE, SECTION 34 TOWNSHIP 14 South RANGE 31 East NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Program: Set bridge plug above 3092' and cap with 35' cement. Mud hole. Cut off 5-1/2" casing. Place 100' cement plug at top of stub. If stub is below top of salt, place 100' cement plug at top of salt. Place 100' cement plug to straddle bottom of 8-5/8" casing. Cap with 10 sacks of cement. Notify Oil Commission ~~at~~ *24 hours before setting bottom plug.*

*All cement plugs must be spotted through tubing.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>B. J. McKinstry</i>	TITLE <i>vice President</i>	DATE <i>10-14-74</i>
APPROVED BY <i>John W. Runyan</i>	TITLE	DATE

CONDITIONS OF APPROVAL, IF ANY: