

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLI
(Other instructions
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 0403826

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO. **Martha Federal**

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., NE, SE, OR BLK. AND
SURVEY OR AREA
Undesignated12. COUNTY OR PARISH 13. STATE
San Juan 8-5-31-8
Chavez New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Imperial-American Management Company

3. ADDRESS OF OPERATOR

507 Midland Savings Bldg. - Midland, Texas 797014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface**660' FNL & 660' FWL**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4272 KB, 4261.5 GR.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data:

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Low oil production rate, high water production rate makes this well uneconomic to continue operating; therefore, we propose to P. & A. as follows:

1. Squeeze off & leave 100' cement plug over perfs 3870-76 w/100 sx Class "C".
2. Load hole with mud.
3. Shoot off 5½" casing at free point- Est. to be above 3000'.
4. Set 100' cement plug @ base of salt section from 1780' to 1880'.
5. Set 100' cement plug @ top of salt section from 1390' to 1490'.
6. Set 45 sx cement plug 370-470', half in & half out of base of surface casing.
7. Set 10 sx cement plug - Surface to 28'.
8. Set location marker & clean up location.

RECEIVED
JAN 28 1970
U.S. GEOLOGICAL SURVEY
INTERNAL NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Area Manager

DATE

1-19-70

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

APPROVED
JAN 23
T. L. BEEKMA

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229

847-485