

UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
HOBBS, NEW MEXICO 88240

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> Mar 13 2 14 PM '91		5. LEASE DESIGNATION AND SERIAL NO. NM-0354427-A	
2. NAME OF OPERATOR Yates Energy Corporation		7. UNIT AGREEMENT NAME	
3. ADDRESS OF OPERATOR P. O. Box 2323, Roswell, New Mexico 88202-2323		8. FARM OR LEASE NAME Amoco Federal	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL & 1980' FEL		9. WELL NO. 2	
14. PERMIT NO. 30-005-20610		10. FIELD AND POOL, OR WILDCAT Cato San Andres	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4192' GL		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Section 1-8S-30E	
		12. COUNTY OR PARISH Chaves	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANE

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon well as follows:

1. Install a 4 1/2" CIBP @ 3500'.
2. Dump 35 sx. cement on CIBP.
3. Cut csg. off at approx. 1800'.
4. Place a 25 sx. cmt. plug 50' inside csg. stub and another 50' out of csg. stub.
5. 35 sx. cmt. plug 328'-228'.
6. 15 sx. cmt. plug @ surface.
7. Install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED Sharon D. O'Connell TITLE Landman

DATE 3-13-91

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

*See Instructions on Reverse Side