

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-

5a. Indicate Type of Lease
State ☐ ☒ ☐
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Yates Energy Corporation	8. From or Lease Name North Cato
3. Address of Operator P.O. Box 2323 Roswell, N.M. 88202	9. Well No. 1
4. Location of Well UNIT LETTER E 1980 FEET FROM THE North LINE AND 660 FEET FROM West LINE, SECTION 4 TOWNSHIP 8S RANGE 30E NMPM.	10. Field and Pool, or Wildcat Cato San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 4036 GR	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is the intention of Yates Energy Corp. to plug and abandon the subject well as follows:

Set CIBP at 3100' (Over perms 3135 - 3310), run tubing, tag plug and place a 10 sack cement plug on top of bridge plug after circulating hole with mud. Free point and cut off 5-1/2" casing. Recover 5-1/2" casing. Spot 35 sack cement plug in and over 5-1/2" casing stub. Spot 35 sack plug at 1022' (Base of 8-5/8" casing). Spot 5 sack at 50'. Install dry hole marker and cement marker in place. Clean location and cut off anchors.

Will start work on approval of intention.

RECEIVED
APR 11 1989
OIL CONSERVATION DIVISION
SANTA FE, NEW MEXICO

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul White TITLE Engineer DATE 4-10-89

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APR 17 1989

RECEIVED

APR 17 1989

OCD
HOBBS OFFICE