

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator DURHAM, INC.	8. Farm or Lease Name Sumerlin
3. Address of Operator P. O. DRAWER 273	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>8-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat Tobac (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4415' DF, 4401' G	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Previous Plug back depth from 9002' to top of plug at 4400', reference C-103 submitted on 10-5-79.

- Plug #6 - Set CIBP at 50' above perf w/35' cement on top.
- Load hole w/10# gal brine.
- Casing w/be cut at freepoint top of cement behind 4-1/2" casing at 3500'. 4-1/2" casing will be pulled.
- Plug #7 - Set 50' plug above & below casing stub.
- Plug #8 - Set 100' plug in 8-5/8" casing at top of salt zone ¹⁸²⁹2795-2895'.
- Plug #9 - 10 Sx Class H at surface.
- Wellhead w/be cut off and 1/4" steel plate w/be welded on stub with 4' dry hole marker installed IAW state rules.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED MILTON BRUMLEY TITLE PRODUCTION SUPT DATE 11-29-79

APPROVED BY Orig. Signed by Jerry Sexton TITLE Dist. 1, Supv. DATE DEC 3 1979

CONDITIONS OF APPROVAL, IF ANY: