

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-005-20699
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-1348
7. Lease Name or Unit Agreement Name Cola ADO State Com
8. Well No. 1
9. Pool name or Wildcat Bar U Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator YATES PETROLEUM CORPORATION	3. Address of Operator 105 South Fourth Street - Artesia, NM 88210
4. Well Location Unit Letter <u>F</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>31</u> Township <u>8S</u> Range <u>33E</u> NMPM Chaves County		

10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4389' GR
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
- Propose to plug and abandon as follows:
1. Pull rods & tubing.
 2. Set CIBP at 9000'± with 35' of cement on top of CIBP.
 3. Set a 25 sack cement plug from 7315-7415' (Top of Abo at 7365').
 4. Pull 4-1/2" casing. Estimate top of cement at 5000'. Set a 25 sack (minimum) (100') cement plug at 4-1/2" casing stub (50' inside & out).
 5. Set a 195' cement plug from 3535-3730' (over 8-5/8" shoe & top of San Andres at 3585').
 6. Set a 100' cement plug (25 sacks minimum) from 362-462'.
 7. Set a 10 sack cement plug at surface.
 8. Install regulation abandonment marker.

NOTIFY OCD - HOBBS (393-6161) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE April 27, 1994
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

TITLE _____ DATE MAY 02 1994

RECEIVED

APR 29 1991

JOHN HOBBS
OFFICE