

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ gas ☐ other ☐ Abandon Oil Well
2. NAME OF OPERATOR
Western Reserves Oil Company
3. ADDRESS OF OPERATOR
P. O. Box 993, Midland, TX 79702
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 2300' FSL & 990' FEL Sec 10 T-8-S
AT TOP PROD. INTERVAL: 3920± R-31-E
AT TOTAL DEPTH: 4150
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

- REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:
- | | | |
|----------------------|-------------------------------------|--------------------------|
| TEST WATER SHUT-OFF | <input type="checkbox"/> | <input type="checkbox"/> |
| FRACTURE TREAT | <input type="checkbox"/> | <input type="checkbox"/> |
| SHOOT OR ACIDIZE | <input type="checkbox"/> | <input type="checkbox"/> |
| REPAIR WELL | <input type="checkbox"/> | <input type="checkbox"/> |
| PULL OR ALTER CASING | <input type="checkbox"/> | <input type="checkbox"/> |
| MULTIPLE COMPLETE | <input type="checkbox"/> | <input type="checkbox"/> |
| CHANGE ZONES | <input type="checkbox"/> | <input type="checkbox"/> |
| ABANDON* | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| (other) | <input type="checkbox"/> | <input type="checkbox"/> |

5. LEASE
NM-19197
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Button Mesa
9. WELL NO.
#1
10. FIELD OR WILDCAT NAME
Undesignated East Siete San Andres
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 10, T-8-S, R-31-E
12. COUNTY OR PARISH
Chaves
13. STATE
NM
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
DF 4324

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP @ 3830± cap with 2 sx. cement.
2. Set 35 sx. cement plug across 4 1/2' casing. stub. Tag this plug.
3. Set 35 sx. cement plug across top of Yates @ 1992'. (2042'-1942')
4. Set 35 sx. cement plug across 8 5/8" csg. shoe 1450'. (1400-1500').
5. Set 10 sx. plug @ surface.
6. Install dry hole marker. Clean location.

Subsurface Safety Valve: Manu. and Type

Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Joe T. Juica TITLE Agent for WR DATE August 9, 1982

APPROVED (This space for Federal or State office use)
APPROVED BY James A. Gillham TITLE District Supervisor DATE AUG 25 1982
CONDITIONS OF APPROVAL, IF ANY

FOR
JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side

RECEIVED
AUG 15 1982
U.S. DEPT. OF THE INTERIOR
MINERAL INVEST. SERVICE
NEW MEXICO

1982
AUG 20 1982
HOBBS OFFICE