

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

U. S. OIL CONS. COMMISSION  
P. O. BOX 1980  
HOBBS, NEW MEXICO 88240  
SUBMIT IN TRIPLIC.  
New Instructions on re-  
verse side

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO

NM-15677A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Strange Federal

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Tomahawk - San Andres

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 25, T-7-S, R-31-E

12. COUNTY OR PARISH 13. STATE

Chaves

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Exxon Corporation

3. ADDRESS OF OPERATOR

P. O. Box 1600, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

660' FSL and 1980' FWL of Sec. 25

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4411 KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) Circ hole w/ 9.5 ppg brine mud
- 2) Set CIBP @ 3770' and cap w/ 4 sx. cmt. Test plug to 500# (isolating the San Andres)
- 3) Spot 25 sx. plug from 1680' to 1480'. (Plug to cover 50' above and below surf. csg. shoe)
- 4) Spot 25 sx. plug from 300' to surf.
- 5) Cut off well head and install abandon well sign.

Estimate work will be done in 3rd quarter of 1987.



18. I hereby certify that the foregoing is true and correct

SIGNED David A. Murray TITLE Permits Supervisor

DATE 4-30-87

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

APPROVED  
PETER W. CHESTER

JUL 2 1987

BUREAU OF LAND MANAGEMENT  
ROSWELL RESOURCE AREA

\*See Instructions on Reverse Side