

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Jalapeno Corporation

3. Address and Telephone No.

PO Box 1608 Albuquerque NM 87103 505-242-2050

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FNL & 330' FWL Sec 6-08S-32E

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 0347394

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

South Tomahawk Fed #1

9. API Well No.

30-005-20926

10. Field and Pool, or Exploratory Area

Tomahawk San Andres

11. County or Parish, State

Chaves NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon well as follows:

- * 1. Set a 35 sx cement plug across perforations and tag plug.
- 2. Cut csg @ approx 1700'
- * 3. Place a 25 sx. cement plug 50' inside stub and another 50' out of csg.
- 4. Place a 25 sx plug 300-400' tag plug.
- 5. Place a 50' Plug.
- 6. Place 10 sx plug @ surface.
- 7. Install plate and dry hole marker.

* 1. Top of plug must be at least to 3980'

* 3. Tag plug across 4 1/2" casing stub. This plug will have to extend at least 50' above the 9 5/8" casing shoe at 1701'. If the 4 1/2" casing is cut & pulled from a different depth a separate 100' cement plug will need to be drilled across the 8 5/8" casing shoe and the plug will need to be tagged.

14. I hereby certify that the foregoing is true and correct

Signed Jeanetta Atkinson

Title Jeanetta Atkinson

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

Date 7/26/95

APPROVED
PETER W. CHESTER
Date 8/1/95
BUREAU OF LAND MANAGEMENT
WELL RESOURCE AREA

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

RECEIVED

JUN 13 1995

JOHN HOBBS
OFFICE